



PRODUCT ASSEMBLY INSTRUCTIONS:



www.wavearmor.net

Item # | Product Name: #301011 3" Bushing/Insert for SLX Ports

Parts List:	Tools Needed:
1. 301003 3" Bushing/Insert Qty 2	1. Ratchet
2. Hardware Bag (6 qty, 3/8 x 1 1/4" Bolts, 6 qty, 3/8 washers	2. 9/16" socket
3.	3.
4.	4.
5.	5.

Assembly Instructions:

Installing the 3" Bushing/Insert in the Wave Port SLX 5 or SLX6

Designed to fit 2 1/2" pipe which has an O.D. of 2 7/8"

1. At the front or rear of the SLX Port align the insert with the post hole. Place the insert into the opening and line up the holes with the threaded inserts in the Port. Secure with the 3/8 x 1 1/4" bolts and washers. Repeat on other side.

